



ELIA
Double flush push-button
REF: 5056302

Dual flush push-button black.

REF. 5056302

COLORES / ACABADOS



02
Negro

ARTÍCULOS

Ref.	Producto/Conjunto	Medidas €/u
5056302	Pulsador Doble descarga Eon3 Negro	48,5 €
Componentes/Instalación		
55483	WC Full Frame Eon. Sistema de instalación para inodoro suspendido en pared ligera. Descarga 6/3 litros, 4,5/3 litros y 4/2 litros.	244,0 €
55480	WC Full Frame Eon Compact. Sistema de instalación para inodoro suspendido en pared ligera. Descarga 6/3 litros, 4,5/3 litros y 4/2 litros.	265,0 €
55485	WC Full Frame Eon Freestanding. Sistema de instalación para inodoro suspendido autoportante. Descarga 6/3 litros, 4,5/3 litros y 4/2 litros.	305,0 €
55484	WC Full Frame Gala Innova. Sistema de instalación para inodoro suspendido Gala Innova. Incluye flexo de alimentación y tubo corrugado para Shower Toilets. Descarga 6/3 litros, 4,5/3 litros y 4/2 litros.	368,0 €
55481	WC Half Frame Eon Compact. Sistema de instalación para inodoro suspendido en pared de obra. Descarga 6/3 litros, 4,5/3 litros y 4/2 litros.	211,0 €
55482	WC Tank Eon Compact. Sistema de instalación para inodoro no suspendido en pared de obra y pared ligera. Descarga 6/3 litros, 4,5/3 litros y 4/2 litros.	141,0 €

INFORMACIÓN DE PRODUCTO

Características
Dual push-button Eon3 Black. Are only compatible with Eon System.

Garantía
Gala products are guaranteed against any manufacturing defects, from the date of purchase of the product, only if the installation has been carried out in accordance with Gala´s installation instructions and, applying the current legislation on electrical and sanitary appliances, by authorised staff. The guarantee period is of 5 years.

Instalación
Please check our product installation manuals.


Certificaciones
High quality is a constant at Gala in order to guarantee the technical and aesthetic features as well as the performance of our products. Please check our product quality certificates.

Mantenimiento
For periodical cleaning use a soft cloth and soap and water. Dry the push-button after cleaning. If you use cleaning products such as gels, liquid cleaners or anti-limescale products, always read the manufacturers´ instructions first. After using the products always rinse the push-button with clean water. Do not use abrasive products such as bio-alcohol, bleach, hydrochloric acid, ammonia, acetone or other similar products. Do not use aggressive scourers.

AMBIENTE



DIBUJOS TÉCNICOS



DESCARGAS

2D

-  91.36 KB  Double flush push-button - Técnico (.AI)
-  73.1 KB  Double flush push-button - Técnico (.DWG)
-  547.27 KB  Double flush push-button - Técnico (.DXF)
-  97.02 KB  Double flush push-button - Técnico (.PDF)